ZIN REPORT: ZIN 1

2019, Custom - Parlee, Z Zero (Road)

Notes:

STEM	SPACER STACK	CRANK LENGTH	PEDALS	SADDLE	BARS SHOES	
-6 ° x 120 mm	50 mm	165 mm	Speedplay	Selle SMP F30c	Parlee	
MEASUREME	NTS & ANGLES					
T ×	Saddle Height: 751 mm BB to center of saddle profile			Handlebar Reach: 518 mm tip of saddle horiz to bar top		
					Handlebar Drop: -56 mm cen of saddle profile to bartop grip, — denotes bar below saddle	
	Saddle Setback: -42 mm BB horiz to front tip of saddle grip, — denotes saddle behind BB		1	Grip Reach: 639 mm tip of saddle horiz to trough of grip		
					Grip Drop: -48 mm cen of saddle to trough of grip, — denotes grip low	
**	Saddle Angle: -5 ° angle of saddle to horizon grip, – denotes nose down		_ + +		Bar Reach: 53 mm center of bar to back end of grip	
	angle of saudic to from 20	ingip, — denotes nose down	7	Center of ball to back at		
Ī	Eff. Seat Tube Angle		⊷	Grip Width: 396 m	m	
7,7	Grip Angle: 20 °	res front end up		BB to Grip Reach:	597 mm	
				Jac a accept of grip		
	Frame Stack: 568 mi	Frame Stack: 568 mm Frame Reach: 376 mm BB to center of headtube top		Handlebar Stack:	559 mm	
				Handlebar Reach: BB to center of bar	Handlebar Reach: 476 mm BB to center of bar	

THIS BIKE FIT PERFORMED USING THE $\ensuremath{\mathsf{RET\"{UL}}}$ SYSTEM



BICYCLE MEASUREMENT DEFINITIONS

DESCRIPTION/DEFINITION KEY KEY DESCRIPTION/DEFINITION Common Bike Definitions (used on all reports) Frame Stack and Reach <u> Handlebar Stack & Reach</u> The horizontal and vertical distance from the The horizontal and vertical distance from the center of the bottom bracket to the center of the center of the bottom bracket to the center of the top of the headtube. handlehar Handlebar Reach Effective Seat Tube Angle The horizontal distance from the front tip of the The angle between horizontal and the saddle saddle to the center of the handlebar. height axis defined in saddle height. Handlebar Drop The vertical distance from the center point of the saddle profile to the top of the handlebar. A negative value signifies the handlebar being lower than the saddle. Saddle Height Saddle Setback The distance from the center of the bottom The horizontal distance from the front tip of the bracket to the horizontal midpoint of the saddle saddle to the center of the bottom bracket. A negative value signifies the saddle being rearward of the bottom bracket. Saddle Angle The angle between horizontal and the line tangent to the top of the saddle. A negative value signifies the nose of the saddle being lower than the rear of the saddle. Road Bike Definitions (used on road reports) BB to Grip Reach Grip Reach The horizontal distance from the center of the The horizontal distance from the front tip of the bottom bracket to the trough of the grip. saddle to the trough of the grip. Grip Drop The vertical distance from the center point of the saddle profile to the trough of the grip. A negative value signifies the grip being lower than the saddle. Grip Angle Bar Reach



The angle between horizontal and the flat

signifies the front of the grip being higher than

segment of the grip. A positive value



The horizontal distance from the top of the

handlebar to the rearmost point of the grip.



BICYCLE MEASUREMENT DEFINITIONS

KEY	DESCRIPTION/DEFINITION	KEY	DESCRIPTION/DEFINITION				
GRIP WIDTH	Grip Width The 3D distance between the midpoints of the grip contours if both grips traced. Otherwise, two times the distance perpendicular from the plane of the bike to the midpoint of the single traced grip contour.						
Tri Bike Definitions (used on tri/tt reports)							
	Arm Pad Stack BB The vertical distance from the center of the bottom bracket to the top of the arm pad.		Arm Pad Reach BB The horizontal distance from the center of the bottom bracket to the back of the arm pad.				
	BB to Grip Reach The horizontal distance from the center of the bottom bracket to the frontmost point of the grip.	<u></u> <u>+</u> <u>+</u> <u>+</u> <u>+</u> <u>+</u> <u>+</u> <u>+</u> <u>+</u> <u>+</u> <u></u>	Arm Pad Reach The horizontal distance from the front tip of the saddle to the back of the arm pad. Arm Pad Drop The vertical distance from the center point of the saddle profile to the top of the arm pad. A negative value signifies the arm pad being lower than the saddle.				
\(\frac{1}{\hat{\chi}}	Grip Reach The horizontal distance from the front tip of the saddle to the frontmost point of the grip. Grip Drop The vertical distance from the center point of the saddle profile to the frontmost point of the grip. A negative value signifies the grip being lower than the saddle.	<u> </u>	Grip Angle The angle between horizontal and the best fit line to the traced grip contour. A positive value signifies the front of the grip being higher than the rear.				
	Arm Pad to Grip Reach The horizontal distance from the back of the arm pad to the frontmost point of the grip.	ARMPAD	Arm Pad Width The 3D distance between the midpoints of the arm pad contours if both grips traced. Otherwise, two times the distance perpendicular from the plane of the bike to the midpoint of the single traced arm pad contour.				
GRIP WIDTH	Grip Width The 3D distance between the midpoints of the grip contours if both grips traced. Otherwise, two times the distance perpendicular from the plane of the bike to the midpoint of the single traced grip contour.						







BICYCLE MEASUREMENT DEFINITIONS





